## **COPPERHEAD XD SCHEDULED LUBRICATION & MAINTENANCE**

SERVICE ITEM		SERVI MA(	CE INT CHINE	PAGE LUBRICANT				
Perform at every indicated month or operating hour interval, whichever comes first.	EACH USE	First month or 20 HRS.	EVERY 3 months or 50 HRS.	EVERY 6 months or 100 HRS.	EVERY year or 300 HRS.	EVERY 2000 HRS.	REFER	LUBRIC
Check engine oil level	$\checkmark$	_					ENGINE MANUAL	EO
Change engine oil		$\checkmark$		$\checkmark$			ENGINE MANUAL	EO
Check air filter	$\checkmark$						ENGINE MANUAL	
Clean air filter			$\checkmark$				ENGINE MANUAL	
Replace air filter					$\checkmark$		ENGINE MANUAL	
Clean sediment cup				$\checkmark$			ENGINE MANUAL	
Clean-readjust spark plug				$\checkmark$			ENGINE MANUAL	
Replace spark plug					$\checkmark$		ENGINE MANUAL	
Check-adjust idle speed					$\checkmark$		ENGINE MANUAL	
Check/readjust valve clearance					$\checkmark$		ENGINE MANUAL	
Clean fuel tank and strainer					$\checkmark$		ENGINE MANUAL	
Check fuel line	Every 2 years (Replace if necessary)						ENGINE MANUAL	
Check fuel level	$\checkmark$						ENGINE MANUAL	
Inspect electrical wiring				$\checkmark$				
Clean oil cooler core exterior			$\checkmark$				C.3.1	
Check oil cooler hoses					$\checkmark$		C.3.1	

DEFINITIONS: EO - ENGINE CRANKCASE OIL HYDO - HYDRAULIC OIL MPGM - MULTIPURPOSE TYPE GREASE WITH MOLYBDENUM DISULFIDE OGL - OPEN GEAR LUBRICANT

## **COPPERHEAD XD SCHEDULED LUBRICATION & MAINTENANCE**

SERVICE ITEM		SERVI MAC	CE INT CHINE	PAGE CE LUBRICANT				
Perform at every indicated month or operating hour interval, whichever comes first.	EACH USE	First month or 20 HRS.	EVERY 3 months or 50 HRS.	6 months or 100	EVERY year or 300 HRS.	EVERY 2000 HRS.	REFER	LUBRIC.
Check hydraulic oil level	$\checkmark$						C.3.1	HYDO
Change hyd. oil filter (return line)					$\checkmark$		C.3.2	
Change hyd. oil in reservoir						$\checkmark$	C.3.3	HYDO
Check hydraulic hoses					$\checkmark$			
Check wheel lug nut tightness								
				•				
Check Vibrator Gear Box Oil	$\checkmark$						C.3.4	EO
Change Vibrator Gear Box Oil					$\checkmark$		C.3.4	EO
Change gear lube in drive motors (0.5 qt. 2 threaded holes, one for filling and one for the level. Fill up to the lower hole.)				<ul> <li>✓</li> </ul>				OGL

DEFINITIONS: EO - ENGINE CRANKCASE OIL HYDO - HYDRAULIC OIL MPGM - MULTIPURPOSE TYPE GREASE WITH MOLYBDENUM DISULFIDE OGL - OPEN GEAR LUBRICANT